



<b>2-3. Operating the lights and windshield wipers.....</b>	<b>139</b>
Headlight switch.....	139
Fog light switch .....	142
Windshield wipers and washer.....	143
Headlight cleaner switch .....	146
<b>2-4. Using other driving systems....</b>	<b>147</b>
Cruise control .....	147
Dynamic radar cruise control.....	150
Intuitive parking assist .....	160
Driving assist systems.....	166
PCS (Pre-Collision System)....	173
<b>2-5. Driving information .....</b>	<b>176</b>
Cargo and luggage.....	176
Vehicle load limits.....	179
Winter driving tips .....	180
Trailer towing .....	182
Dinghy towing .....	183

### 3 Interior features

<b>3-1. Using the air conditioning system and defogger .....</b>	<b>186</b>
Automatic air conditioning system .....	186
Rear window and outside rear view mirror defoggers .....	194
<b>3-2. Using the audio system.....</b>	<b>195</b>
Audio system types .....	195
Using the radio.....	198
Using the CD player .....	205
Playing back MP3 and WMA discs.....	211
Optimal use of the audio system .....	217
Using the AUX adapter.....	220
Using the steering wheel audio switches .....	221
<b>3-3. Using the interior lights .....</b>	<b>223</b>
Interior lights list.....	223
• Interior lights .....	225
• Personal lights .....	225
<b>3-4. Using the storage features....</b>	<b>227</b>
List of storage features .....	227
• Glove box .....	227
• Console box.....	228
• Overhead console .....	229
• Cup holders.....	230
• Bottle holders/door pockets.....	232
<b>3-5. Other interior features .....</b>	<b>233</b>
Sun visors.....	233
Vanity mirror.....	234
Clock.....	235
Satellite switches .....	236
Ashtrays .....	239
Cigarette lighter .....	240

Power outlet .....	241
Seat heaters .....	242
Seat heaters and ventilators ....	244
Armrest .....	246
Trunk storage extension .....	247
Coat hooks .....	249
Floor mat .....	250
Trunk features .....	251
Garage door opener .....	254
Compass .....	259

## 4 Maintenance and care

### 4-1. Maintenance and care..... 264

Cleaning and protecting the vehicle exterior .....	264
Cleaning and protecting the vehicle interior .....	267

### 4-2. Maintenance ..... 270

Maintenance requirements .....	270
General maintenance .....	272
Emission inspection and maintenance (I/M) programs .....	275

### 4-3. Do-it-yourself

#### **maintenance..... 276**

Do-it-yourself service precautions .....	276
Hood .....	279
Positioning a floor jack .....	280
Engine compartment .....	282
Tires .....	296
Tire inflation pressure .....	307
Wheels .....	311
Air conditioning filter .....	313
Electronic key battery .....	316
Checking and replacing fuses .....	318
Headlight aim .....	332
Light bulbs .....	334

## 5 When trouble arises

### 5-1. Essential information..... 340

If your vehicle needs to be towed .....	340
If you think something is wrong .....	346
Fuel pump shut off system .....	347
Event data recorder .....	348

5-2. Steps to take in an emergency ..... 350

    If a warning light turns on or a warning buzzer sounds... ..... 350

    If a warning message is displayed..... 360

    If you have a flat tire..... 374

    If the engine will not start ..... 383

    If the shift lever cannot be shifted from P ..... 384

    If you lose your keys ..... 385

    If the electronic key does not operate properly ..... 386

    If the vehicle battery is discharged ..... 389

    If your vehicle overheats ..... 392

    If the vehicle becomes stuck ... 395

6 Vehicle specifications

6-1. Specifications..... 398

    Maintenance data (fuel, oil level, etc.)..... 398

    Fuel information..... 409

    Tire information..... 412

6-2. Customization ..... 424

    Customizable features ..... 424

6-3. Initialization ..... 429

    Items to initialize ..... 429

7 For owners

    Reporting safety defects for U.S. owners..... 432

    Seat belt instructions for Canadian owners (in French)..... 433

Index

    Abbreviation list ..... 436

    Alphabetical index..... 438

    What to do if... ..... 449